


WGS-HQL

Holder for storage of EOAT with Quick-Lock adapters.

Two types of holders for each size of Quick change system are available.


NEW!



WGS-HQLV

For mounting on walls

Article no	Type	A	B	C	D	E	F
022403	WGS-HQLV Mini	153	22	50	133	80	Ø6,5
022404	WGS-HQLV Midi	153	22	50	133	80	Ø6,5
022405	WGS-HQLV Maxi	248	42	100	218	145	Ø8.2



WGS-HQLN

For mounting on safetywalls with wire mesh
(WSS safety wall elements)

NEW!

Article no	Type	A	B	C	D	E
022423	WGS-HQLN Mini	153	22	Ø6	66	80
022424	WGS-HQLN Midi	153	22	Ø6	66	80
022425	WGS-HQLN Maxi	248	42	Ø6	131	145